

Stick On Blinds

TRIMMABLE TO ANY SIZE



Measure



Cut



Stick



No tools. No drilling. Removes cleanly.

Step 1 – Measure

Use a tape measure to find the exact width of your window. Mark your measurement on the blind lightly with a pencil.

Step 2 – Cut

Trim the blind to your required width using scissors. To ensure a neat and straight finish, trim one fold at a time.

Step 3 – Stick

Peel off the adhesive backing. Carefully align the blind at the top of your window frame. Press firmly along the strip to secure in place.



FURNISHED